

# MOD-TRADITIONAL

## 3ft Fence Panel Assembly Instructions

### Unpack all contents

#### Contents:

- 1-Top Rail
- 1-Bottom Rail
- 2-Top Rail hooks
- 2-Bottom Rail hooks
- 5-Mod-Traditional Slats
- 8-Pop Rivets
- 6-Self-Tapping Screws

#### You Will Also Need:

- Pop Rivet Tool  
(Included with Mod-Posts)
- Phillips Screw Driver or Drill



### Step 1

Layout Top Rail and Bottom Rail with the screw holes facing up. The holes on the Picket fence on both rails should face each other.



### Step 2

Insert longer bottom rail hooks into either side of the bottom rail with hooks pointing down. Rivet bottom hooks to bottom rail.



**Step 3**

Insert shorter top rail hooks into either side of the top rail with hooks pointing down. Rivet top hooks to rail top.



**Step 4**

Insert the 5 Mod-Traditional Vertical Pickets into bottom rail first, then top rail.



**Step 5**

Pull rails together tightly and screw top and bottom rails to the pickets at the 6 screw holes.



**You have now successfully built your Mod-Traditional Panel!**



**Watch  
the Video**

