

MOD-TRADITIONAL

6ft Gate Assembly Instructions

Unpack all contents

Contents:

- 2-Top Rails
- 2-Bottom Rails
- 2-Wheels
- 1 Latch Set
- 10-Mod-Traditional Slats
- 12-Self-Tapping Screws (White)
- 12-Screws (Black)

You Will Also Need:

- Phillips Screwdriver or Drill



Step 1

Layout top and bottom rails and line up the ends without hooks.

Pro Tip: Position hooks on outside pointed down for assembly.




Step 2

Bottom Rails have the long hooks - make sure they're facing down.



Step 3

Top Rails have the short hooks - make sure they're facing down.



Step 4

Attaching Wheels to Bottom Rails:

Note the pre-drilled holes on the bottom rails. Line up wheels with holes and attach with BLACK screws.



Step 5

Attaching Latch to Top Rails:

Important: The left side latch piece has the moving arm piece



Step 6

Attaching Latch to Top Rails:

Important: The left side latch piece has the moving arm piece.

Line up screw holes with latch and screw both latches to top rails.

Pro Tip: Pre-drilled holes are different on both rails and will help identify latch locations



Step 7

Separate top and bottom rails and layout all 10 vertical slats. DO NOT insert yet, see next step.



Step 8

Fully insert vertical slats into bottom rail until you feel and hear the click.



Step 9

Now pull top and bottom rails together until you feel and hear the click of vertical slats fully inserting into top rail.



Step 10

Screw 6 self-tapping WHITE screws into 6 pre-drilled screw holes (3 on bottom rail, 3 on top rail).



Step 11

Repeat steps for vertical slat installation for second set of top and bottom rails.



You have now successfully built your Mod-Traditional Gate!

Watch the Video

